

ASSEMBLY INSTRUCTION

DESC : SHOE CABINET WITH 2 DOOR

MODEL : HM 2230.01

SOFT DRY CLOTH	CHEMICAL	HEAT	KEEP DRY	HANDLE WITH CARE	DO NOT USE KNIFE	

PART LIST	
A	WOOD 1X12 1X12 1X25
B	CD 15MM 1X32 1X32 1X4
C	CSK CAP 1X30MM 1X30MM 1X4
D	MOOR 5/8 1X30 1X30
E	ALLEN KEY 1X1 1X1
F	METAL SHELF SUPPORT 1X16 1X16
G	MINIFIX 564-568 6 SETS 1X10
H	MINIFIX CAP 1X10 1X10
I	HINGES 7/8 4 SETS 1X2
J	HANDLE 502 (METAL) 1X2 1X2
K	2 PIN STOPPER 1X2 1X2
L	30/100 PVC LEG 1X4 1X4

STEP 1

STEP 2

STEP 3

STEP 4

STEP 5

STEP 6

STEP 7

STEP 8

STEP 9

STEP 10

STEP 11

STEP 12

STEP 13

COMPLETED

